


Instruction for adding Wansview IP camera to Bule Iris

Download link : <http://blueirissoftware.com/>

Add camera:

Please click  to add camera, then follow below images to enter parameters about camera:

IP or host name: enter camera's ip address

Http port: camera's port number

RTSP port: camera's rtsp port(the camera rtsp port is 554 by default)

User/Password: enter camera's user name and password

Make/Model: choose Wansview NCM GA/GB

Path: /live/ch0 or ch1 or chn2

